

TRIMBLE iSCOPE APP TECHNICAL NOTES



The Trimble® iScope App provides an interactive map view of the location of rovers currently receiving corrections or of recent rover sessions. The Trimble iScope App operates on the Trimble Pivot™ platform, the foundation for multiple Infrastructure apps that serve various markets and their specific needs.

TRIMBLE iSCOPE APP

Understanding where users are working is important information for both network operators and field crew managers. The Trimble iScope App enables the VRS iScope™ service functions in the Pivot web interface.

The VRS iScope Live! service provides real-time views of active VRS™ network logins in the field, and VRS iScope service provides a history of recent sessions performed by each login. Remotely accessible interactive map views show current activity or the trajectory of recent sessions, making it easy for field crew managers to schedule, track, and manage projects more efficiently. For user accounts, all logins associated with the primary user may be viewed.


Network operators may view the activity of any or all users and logins. This allows the network operator to review current or recent subscriber activity as an aid in understanding how subscribers use correction streams and as an aid in resolving user queries.

The interactive map view supports various map providers such as Google or Bing Maps satellite imagery to add useful contextual information about the location of users. For field crew managers, this makes it easy to visualize work progress. In addition, satellite or terrestrial imagery may allow identification of possible sources of excessive multipath or satellite signal blockage at the user location. This may help in analyzing performance issues.

iSCOPE PAGES IN TRIMBLE PIVOT WEB APPLICATION

The Trimble Pivot platform includes a basic web installation. Some licensed apps add their own web pages, providing additional functions. Trimble iScope App includes the following web pages:

- iScope
- iScope Live!



iScope Live! overview on the location and the color coded status of active users and logins



VRS iScope view of a field session selected from the history of sessions associated with an NTRIP login

ORDER INFORMATION

Default Configuration	Part Number
Trimble iScope App	96803-40

NORTH AMERICA

Trimble Engineering
& Construction Group
10355 Westmoor Drive, Suite 100
Westminster, Colorado 80021 • USA
800-480-0510 (Toll Free)
+1 720-887-6100 Phone
+1 720-887-6101 Fax

EUROPE

Trimble Germany GmbH
Am Prime Parc 11
65479 Raunheim • GERMANY
+49-6142-2100-0 Phone
+49-6142-2100-550 Fax

ASIA-PACIFIC

Trimble Navigation
Singapore Pty Limited
80 Marine Parade Road
#22-06, Parkway Parade
Singapore 449269 • SINGAPORE
+65-6348-2212 Phone
+65-6348-2232 Fax

TRIMBLE AUTHORIZED DISTRIBUTION PARTNER



www.trimble.com